

BMS Blow Off Valve Adapter for Gen3 BMW B58TU2 Install Guide

Last updated 6/16/2023

Use subject to terms and conditions posted at <https://burgertuning.com/pages/terms>

THIS PART IS LEGAL FOR USE ONLY IN COMPETITION RACING VEHICLES AS DEFINED UNDER CALIFORNIA LAW AND IS NOT LEGAL FOR USE IN ANY OTHER MOTOR VEHICLE. California law defines a "racing vehicle" as "a competition vehicle not used on public highways." (Calif. Health & Safety Code 39048) This part may only be used on competition racing vehicles operated exclusively on a closed course in conjunction with a sanctioned racing event. Competition-only motor vehicles may not be driven to a racing event on a public highway and must be transported on a trailer or other carrier. USE OF THIS PART IN ANY OTHER VEHICLE MAY SUBJECT YOU TO FINES AND PENALTIES FOR VIOLATION OF FEDERAL AND/OR STATE LAW, WILL VOID YOUR WARRANTY FROM BURGER MOTORSPORTS, INC, AND CAN VOID YOUR VEHICLE'S WARRANTY. It is your responsibility to comply with all applicable federal and state laws relating to the use of this part, and Burger Motorsports, INC hereby disclaims any liability resulting from the failure to use this part in compliance with all applicable federal and state laws.



Remove the passenger side strut brace by removing the two bolts.



Remove the plug from the sensor circled in red and loosen the hose clamp to the right of it. Next pull upward on the airbox and remove it from the vehicle to expose the factory diverter valve.



Locate the diver valve circled in red and unscrew the 3 factory screws.



Now place the BMS BOV adapter in between the diverter valve and the car and use the included longer screws and tighten them.



Replace intake, tighten clamp, and plug sensor back in to complete the installation.



Questions? Ask the pros support@burgertuning.com