

## **BMS Differential Brace for 2016+ Infiniti Q50/Q60 3.0L Install Guide**

Last updated 7/11/2025

Use subject to terms and conditions posted at <https://burgertuning.com/pages/terms>



Remove the two cross member bolts marked in red. These will not be reused.

Next, remove the (3) lower differential cover bolts marked with the green arrows in the order shown. These will be reused when installing the BMS differential brace.



Place the included spacers between the BMS differential brace and the vehicle. Loosely tighten the two included extended bolts along with the 3 lower factory bolts.



Next, tighten the (3) factory bolts and tighten the (2) upper crossmember bolts.



Installation complete.