

BMS Differential Support Bracket Brace for G Chassis BMW/Supra Install Guide


Last updated 12/11/2025

Use subject to terms and conditions posted at <https://burgertuning.com/pages/terms>


THIS PART IS LEGAL FOR USE ONLY IN COMPETITION RACING VEHICLES AS DEFINED UNDER CALIFORNIA LAW AND IS NOT LEGAL FOR USE IN ANY OTHER MOTOR VEHICLE. California law defines a "racing vehicle" as "a competition vehicle not used on public highways." (Calif. Health & Safety Code 39048) This part may only be used on competition racing vehicles operated exclusively on a closed course in conjunction with a sanctioned racing event. Competition-only motor vehicles may not be driven to a racing event on a public highway and must be transported on a trailer or other carrier. USE OF THIS PART IN ANY OTHER VEHICLE MAY SUBJECT YOU TO FINES AND PENALTIES FOR VIOLATION OF FEDERAL AND/OR STATE LAW, WILL VOID YOUR WARRANTY FROM BURGER MOTORSPORTS, INC, AND CAN VOID YOUR VEHICLE'S WARRANTY. It is your responsibility to comply with all applicable federal and state laws relating to the use of this part, and Burger Motorsports, INC hereby disclaims any liability resulting from the failure to use this part in compliance with all applicable federal and state laws.




Remove the 4 factory torx bolts on the differential.



For the 2020-2026 Toyota Supra, remove the damper weight using an E14 socket along with the threaded tab inside the subframe and put these aside. They are no longer needed with the diff brace in place.



Put the 4 billet spacers between the BMS diff braces and screw them in with the supplied bolts. The two holes below the subframe will be used as templates for the required $\frac{1}{2}$ " drill holes.



Use a $\frac{1}{2}$ " drill bit and drill the holes all the way through the top and bottom of the subframe. Make sure the drilled holes are horizontally level. A long drill bit will be needed to drill with the brace on. For shorter bits the brace can be removed and the holes drilled.



Next place the long bolts through the subframe with the washers and bolts shown in the position below. Double check all the nuts and bolts are tight.

